
Comparative Proteomics Kit I: Protein Profiler Module – Quick Guide


Lesson 1 Quick Guide

- 1 Label one 1.5 ml fliptop micro tube for each of five fish samples. Also label one screwcap micro tube for each fish sample.
- 2. Add 250 μl of Bio-Rad Laemmli sample buffer to each labeled **fliptop** microtube.
- Cut a piece of each fish muscle about 0.25 x 0.25 x 0.25 cm³ () and transfer each piece into a labeled fliptop micro test tube. Close the lids.
- 4. Flick the microtubes 15 times to agitate the tissue in the sample buffer.
- 5. Incubate for 5 minutes at room temperature.
- Carefully transfer the buffer by pouring from each fliptop microtube into a labeled screwcap microtube. Do not transfer the fish!
- 7. Heat the fish samples in screwcap microtubes for 5 minutes at 95°C.


Lesson 2 Quick Guide

- 1. Set up Mini-PROTEAN 3 gel box and add 1x TGS electrophoresis buffer to the chamber.
- Prepare a Ready Gel cassette by cutting along the black line on the bottom of the cassette with a razor blade and pulling off the plastic strip, as indicated on gel cassette.
- Remove the comb from the Ready Gel cassette.
- Place Ready Gel cassette into the electrode assembly with the short plate facing inward. Place a buffer dam or another Ready Gel cassette on the opposite side of the electrode assembly, with notch on buffer dam facing inward.







5. Slide gel cassette, buffer dam, and electrode assembly into the clamping frame.



6. Press down the electrode assembly while closing the two cam levers of the clamping frame.




7. Lower the inner chamber into the mini tank.



- 8. Completely fill the inner chamber with 1x TGS electrophoresis buffer, making sure the buffer covers the short plate (~150 ml).
- 9. Fill mini tank approximately 200 ml of 1x TGS electrophoresis buffer.


10. Plate sample loading guide on top of the electrode assembly.




- 11. Heat fish samples and actin and myosin standard to 95°C for 2–5 min.
- 12. Load your gel:

<u>Lane</u>	<u>Volume</u>	<u>Sample</u>
1 & 2	empty	empty
3	5 µl	Precision Plus Protein Kaleidoscope prestained standards (Stds)
4	10 µl	fish sample 1
5	10 µl	fish sample 2
6	10 µl	fish sample 3
7	10 µl	fish sample 4
8	10 µl	fish sample 5
9	10 µl	actin and myosin standard
		(AM)
10	empty	empty

13. Electrophorese for 30 minutes at 200 V in 1x TGS electrophoresis buffer.



14. After electrophoresis, remove gel from cassette and transfer gel to a container with 25 ml Bio-Safe Coomassie blue stain per gel and stain gel for 1 hour, with gentle shaking for best results.



Lesson 3 Quick Guide

- Discard stain and destain gels in a large volume of water for at least 30 minutes to overnight, changing the water at least once. Blue-stained bands will be visible on a clear gel after destaining.
- 2. Dry gels using GelAir cellophane.






Fig. 11. Assembling the Mini-PROTEAN 3 cell.

Student Manual



Bio-Rad Laboratories, Inc.

Life Science Group Web site www.bio-rad.com USA 800 4BIORAD Australia 02 9914 2800 Austria 01 877 89 01 Belgium 09 385 55 11 Brazil 55 21 3237 9400 Canada 905 712 2771 China 86 21 6426 0808 Czech Republic 420 241 430 532 Denmark 44 52 10 00 Finland 09 804 22 00 France 01 47 95 69 65 Germany 089 318 84 0 Greece 30 210 777 4396 Hong Kong 852 2789 3300 Hungary 36 1 455 8800 India 91 124 4029300/5013478 Israel 03 963 6050 Italy 39 02 216091 Japan 03 5811 6270 Korea 82 2 3473 4460 Mexico 55 500 520 The Netherlands 0318 540666 New Zealand 64 9415 2280 Norway 23 38 41 30 Poland 48 22 331 99 99 Portugal 351 21 472 7700 Russia 7 095 721 14 04 Singapore 65 6415 3188 South Africa 27 0861 246 723 Spain 34 91 590 5200 Sweden 08 555 12700 Switzerland 061 717 95 55 Taiwan 886 2 2578 7189/2578 7241 United Kingdom 020 8328 2000

Bulletin 5464 US/EG Rev A 06-0335 0506 Sig 1205